# 5998 WOMEN'S CONWAY FLATBACK RIB JACKET

# **WOMEN'S XS-3XL**

- :: 60% Cotton/ 40% Polyester Flat Back Rib Knit
- :: Lightweight transitional piece with abundant layering options
- :: Coordinates with Men's Conway Flatback Rib Pullover 9910





CHARLES RIVER

## **COMFORT & CONVENIENCE**

:: Full Zip Mock neck design with set-in sleeves

:: Contrast stitching for a modern yet sporty feel

:: Low profile on seam pockets

:: Lightweight transitional piece with abundant layering options

## **FABRIC**

60% Cotton/ 40% Polyester Flat Back Rib Knit (8.85 oz/yd2, 300GSM)

#### **SIZES**

Women's Sizes XS-3XL

## **COLORS**

010 Black, 110 Charcoal, 240 Navy Heather, 518 Ivory Heather

#### **GARMENT CARE**

For Better Results Turn Inside Out, Machine Wash Cold with like colors, Tumble Dry Low, Do not Bleach, Do Not Iron, Do Not Dry Clean 010 BLACK

110 CHARCOAL

240 NAVY HEATHER

518 IVORY HEATHER



CONWAY FLATBACK RIB JACKET WOMEN'S 5998	XS	S	М	L	XL	2XL	3XL	TOLERANCE
BODY LENGTH measure from neck (CB neck)	25	25½	26	26¾	271/2	28	28½	1/2 +/-
SHOULDER TO SHOULDER	141/4	14¾	151/4	16	16¾	171/2	181/4	1/4 +/-
CHEST WIDTH measure 1 inch below armhole	18½	191/2	20½	22	23½	25½	271/2	1/2 +/-
BOTTOM OPENING WIDTH RELAXED 1/2	191/2	201/2	21½	23	241/2	26½	281/2	1/2 +/-
SLEEVE LENGTH measure from CB	313/4	32%	33	33¾	341/2	35	35½	1/2 +/-

KEY TO COMMONLY ABBREVIATED SPEC INFORMATION (ALL MEASUREMENTS ARE IN INCHES)

CB = CENTER BACK

CHEST 1 INCH DOWN = MEASURE THE FRONT OF THE GARMENT 1 INCH DOWN FROM THE ARMHOLE

1/2 = MEASURE ONLY THE FRONT OF THE GARMENT, THEN DOUBLE THAT MEASUREMENT TO GET THE TOTAL CIRCUMFERENCE

RELAXED = DO NOT STRETCH THE GARMENT IF IT HAS ELASTIC TO MEASURE, SIMPLY LEAVE THE ELASTIC RELAXED

STRETCHED = STRETCH THE GARMENT IF IT HAS ELASTIC TO MEASURE, MEASURE STRETCHED

